
# **Telephone and Voicemail Instructions**

### Icon Meanings


$$(\stackrel{\square}{co})$$
 = Flexible CO button  $\Rightarrow$  = Off-hook  $\Rightarrow$  = On-hook  $\Rightarrow$  = Talk  $\Rightarrow$  = Confirmation Tone

#### **Making Calls**




<sup>\*\*</sup> One-touch dialing is limited to 8 lines

If there are more than 8 telephone numbers you wish to store, Personal Speed Dailing is also available. It can store up to 99 telephone numbers.




### **During a Conversation**



## For Conference call or Multiple Party Conversation


Please note the conference call feature is not available on your Panasonic KX-NT321 phone unless it is pre-programmed in advance.



## **Other Features**

To pick up a call from another extension

Dial \*41 plus the extension



# **Voicemail Instructions**

From your own extension				
From your own extension  VPS extension no. ►  Mailbox Password* #  * If you have no password, you can skip the last step.	Hancock St Holmes St South St Washington St	3399 3399 6699 6880	**Please note each clinic might has a different VPS extension number	

From someone else's extension				
From someone else's extension  VPS extension no. ►  Mailbox no. ►  Mailbox Password*  If you have no password, you can skip the last step.	Hancock St & Holmes St 617-318-3399 South St 617- 457-6699 Washington St 617-521-6880	** Ex, If I want to check my voicemail from external line. "I dial 617-457- 6699, #6* plus (Ext), and enter password."		

Other key features while accessing the voicemail system				
To skip a greeting	Press 2			
To backup 5 seconds in a message	Press 5			
To backup one menu	Press *			
To delete a message in your mail	After listening to message press 3			
To play next message	After listening to first message press 1 and			
	then 2			
To repeat a message	After listening to message press 1			
To transfer a message to an another	After listening to message press 7			
mailbox				
To repeat previous message	After listening to message press 1 1			
To have a copy of your voicemail	Send an email <a href="mailto:sma@scchc.org">sma@scchc.org</a> to sign up			
messages to be forwarded to your				
email account				

# **Other Settings**

Speaker volume	While in a hands-free conversation	n S D		
Handset/Headset volume*1	While using the handset or headset			
Ringer volume	While on-hook or receiving a call	Press <b>Up</b> to increase or <b>Down</b> to decrease the volume.		
LCD Contrast While on-hook  PROGRAM ▶ ① ① ▶ AUTO DIAL STORE ▶ STORE ▶ PROGRAM STORE				
PROGRAM OR INTERCOM Press 2 times.    CO   (CO)   (				

<sup>\*1</sup> If you hear your own voice through the handset or headset, decrease the volume.

## **Other Reference Manuals**

Panasonic KX-NT551 User Guide
Panasonic KX-NT560 User Guide
Voicemail Subscriber Service Map

<sup>\*2</sup> The ring tone pattern of patterns 09 to 30 is the same as pattern 01.